


Project: <b>DAIRYLAND STORAGE</b>	Job No: <b>20788-001</b>	Boring No: <b>TEST PIT 1</b>
Client: <b>Dairyland Storage</b>	Drilled By: <b>AC EXCAVATING</b>	Elevation: <b>672.1</b>
Location: <b>SHEBOYGAN, WI</b>	Drilling Begun: <b>1/27/26</b>	Drilling Completed: <b>1/27/26</b>
SAMPLE TYPE <input checked="" type="checkbox"/> 1" Geoprobe <input type="checkbox"/> No Recovery <input checked="" type="checkbox"/> Grab Sample <input type="checkbox"/> Auger Sample <input type="checkbox"/> 3" Shelby Tube <input type="checkbox"/> 2" Split Spoon		




2019 GEOTLOG GINT.GPJ STANDARD TEMPLATE.GDT 2/12/26 15:42

**MILLER ENGINEERS SCIENTISTS**

Date <b>01/27/2026</b> Time <b>12:30</b> <u>9</u> ft. _____ ft.	Date: <b>1/27/2026</b>	Crew: <b>NATE</b>
Date _____ Time _____ _____ ft. _____ ft.	Material: <b>SOIL CUTTING</b>	Rig: <b>BACKHOE</b>
Date _____ Time _____ _____ ft. _____ ft.		Method: <b>EXCAVATE</b>

Project: <b>DAIRYLAND STORAGE</b>	Job No: <b>20788-001</b>	Boring No: <b>TEST PIT 2</b>
Client: <b>Dairyland Storage</b>	Drilled By: <b>AC EXCAVATING</b>	Elevation: <b>669.7</b>
Location: <b>SHEBOYGAN, WI</b>	Drilling Begun: <b>1/27/26</b>	Drilling Completed: <b>1/27/26</b>
SAMPLE TYPE <input checked="" type="checkbox"/> 1" Geoprobe <input type="checkbox"/> No Recovery <input checked="" type="checkbox"/> Grab Sample <input type="checkbox"/> Auger Sample <input type="checkbox"/> 3" Shelby Tube <input type="checkbox"/> 2" Split Spoon		




2019 GEOTLOG GINT.GPJ STANDARD TEMPLATE.GDT 2/12/26 15:42

**MILLER ENGINEERS SCIENTISTS**

Date <b>01/27/2026</b> Time <b>12:50</b> <u>8.5</u> ft. _____ ft.	Borehole Abandonment	Crew: <b>NATE</b>
Date _____ Time _____ ft. _____ ft.	Date: <b>1/27/2026</b>	Rig: <b>BACKHOE</b>
Date _____ Time _____ ft. _____ ft.	Material: <b>SOIL CUTTING</b>	Method: <b>EXCAVATE</b>

Project: <b>DAIRYLAND STORAGE</b>	Job No: <b>20788-001</b>	Boring No: <b>TEST PIT 3</b>
Client: <b>Dairyland Storage</b>	Drilled By: <b>AC EXCAVATING</b>	Elevation: <b>670.8</b>
Location: <b>SHEBOYGAN, WI</b>	Drilling Begun: <b>1/27/26</b>	Drilling Completed: <b>1/27/26</b>
SAMPLE TYPE <input checked="" type="checkbox"/> 1" Geoprobe <input type="checkbox"/> No Recovery <input type="checkbox"/> Grab Sample <input type="checkbox"/> Auger Sample <input checked="" type="checkbox"/> 3" Shelby Tube <input type="checkbox"/> 2" Split Spoon		



2019 GEOTLOG GINT.GPJ STANDARD TEMPLATE.GDT 2/12/26 15:42

**MILLER ENGINEERS SCIENTISTS**

Date <b>01/27/2026</b> Time <b>13:10</b> <u>5.5</u> ft. _____ ft.	Water Level	Cave-in Depth	Borehole Abandonment	Crew: <b>NATE</b>
Date _____ Time _____ ft. _____ ft.			Date: <b>1/27/2026</b>	Rig: <b>BACKHOE</b>
Date _____ Time _____ ft. _____ ft.			Material: <b>SOIL CUTTING</b>	Method: <b>EXCAVATE</b>